


Remote Control User Guide



What's on TV?

There's more than one way to see what's showing on TV.

Info Button: Press Info once for a brief description of the program you are viewing. Press Info again for more details.

OK Button: Press OK to show the "Zapper Bar." You'll see what's showing now.

Guide Button: This is the most comprehensive view of what's on. Go ahead and page through ... you're bound to find something to watch.

Favorites

Create Favorite Lists:

There are eight pre-defined favorite lists named: Favorite1, Favorite2, etc.

1. Press Menu. Arrow down to My TV and then arrow right to Edit Favorites. Press OK.
2. To select your favorites list move the right and left arrow button. Channels included in the Favorite List are marked with a v'. Using the arrow buttons, move through the channels and press OK to add or remove a channel to your Favorite List.
3. When done, press the blue button to save your changes.

Using Favorites Lists:

1. Press FAV. By default, your list is All channels.
2. Arrow up/down to choose a Favorite List.
3. Use either the Channel Up/Down button or the Arrow buttons to move between channels in a list. Or, use the number keys to select a channel.
4. To leave Favorite mode, press FAV.

Parental Controls

Set Program Rating Limits: To control the types of programming that can be viewed, you may set program limits based on motion-picture ratings (G, PG, R, etc.) or TV ratings (TV-G,TV-14, etc.) using the Parental Rating option in My Settings. If you attempt to tune to a channel that is airing a program with a rating at or above your rating limit, you must enter a PIN to view the program.

Set Locked Channels: You can lock entire channels via the Channel Locks option in My Settings so that they require a PIN to view programming. You may prevent locked channels from showing in the channel guide via the General Settings (locked channels would still be accessible using the number keys).